

This Page Is Inserted by IFW Operations  
and is not a part of the Official Record

## **BEST AVAILABLE IMAGES**

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images may include (but are not limited to):

- BLACK BORDERS
- TEXT CUT OFF AT TOP, BOTTOM OR SIDES
- FADED TEXT
- ILLEGIBLE TEXT
- SKEWED/SLANTED IMAGES
- COLORED PHOTOS
- BLACK OR VERY BLACK AND WHITE DARK PHOTOS
- GRAY SCALE DOCUMENTS

IMAGES ARE BEST AVAILABLE COPY.

**As rescanning documents *will not* correct images,  
please do not report the images to the  
Image Problems Mailbox.**




FIG. 1




FIG. 2




FIG. 3

+




FIG. 4

+




FIG. 5

007630-6542550




FIG. 6




FIG. 7






FIG. 8





FIG. 9

+



+

<i>Command</i>	<i>Description</i>
connect	Connect a virtual console session to an SRM Firmware instance
disconnect	Disconnect a virtual console session from an SRM Firmware instance
power {off, on} <i>item</i>	Change the power state of an item (CPU, 8P unit, I/O Drawer)
halt <i>processor</i>	Issue a HALT to an EV7 processor (specified by processor ID)
reset [ <i>partition</i> ]	Issue a system reset or a reset to the specified partition
reset <i>processor</i>	Issue a Reset to an EV7 processor (specified by processor ID)
reset { CMM, MBM, PBM}	Issue a Reset to one of the Server Management processors
set manufacturing	Set serial number, other FRU data
set partition	Define the number of partitions, assign partitionable resources to each partition, define the partition permissions.
show config	Show the entire system configuration
show CPU { <i>processor</i> }	Show data on an EV7 CPU (specified by processor ID) or all CPUs
show LAN	Show the nodes on the Server Management LAN
show memory	Show information on memory configuration
show partitions	Show the defined partition data
show FRU	Show the FRU data for the system FRUs
show power	Show the thermal and voltage sensor data
show error	Show the non-volatile saved error state
clear error	Clear the non-volatile saved error state
update	Update system firmware
date	Set / show the server management time
examine / deposit	Display / modify memory
test <i>processor n</i>	Run the test identified by <i>n</i> on the specified <i>processor</i> ID
set test signal <i>processor n</i>	Assert cable test signal for port <i>n</i> (N, S, E, W, I/O) on the specified <i>processor</i> ID and light the cable LED.
clear test signal <i>processor n</i>	De-assert cable test signal for port <i>n</i> (N, S, E, W, I/O) on the specified <i>processor</i> ID and extinguish the cable LED.
check test signal <i>processor n</i>	Test cable test signal for port <i>n</i> (N, S, E, W, I/O) on the specified <i>processor</i> ID.

*External Server Management Commands*

Fig. 11

<i>Command</i>	<i>Description</i>
PutChar	Send a character to the operator display
GetChar	Get a character from the operator keyboard
SetTermInt	Set operator terminal interrupt setting
Hello	Announce the present of a Server Management member
Poll	Probe for the presence of a specific Server Management member
No-op	No operation, used for testing
SysError <i>data</i>	System error state information to be saved
FRUError <i>id</i> , <i>data</i>	Store FRU error <i>data</i> in the FRU specified by <i>id</i>

*Internal Server Management Commands*

Fig. 12


BB\_WATCH Data

**Fig. 13**

[illegible]

## CSB Messages

Fig. 14



*Server Management Hardware Overview*

Fig. 15



001600 35425960





Fig-16





*Rack and Box Thumbwheel Scheme*

**Fig. 17**

Task	How Many	Where
Group Leader	1 per Marvel System <sup>1</sup>	Lowest MBM in group
PMU Server	1 per Marvel System <sup>1</sup>	Lowest MBM in group
Partition Coordinator	1 per hard partition; max 8 per MBM	MBM with lowest EV7 in hard partition
Telnet Server	2 per subpartition (COM0,COM1)	Grandparent MBM of primary EV7
DHCP	1 per Marvel System <sup>1</sup>	Lowest MBM in group

*MBM Task Attributes*

Fig. 18



MBM Firmware Overview  
FIG. 19




Fig. 20


General Phase	Group Changes	Specific Steps	Notes
Independent Processing	Unaffected	POST	
		W Poll Status and State	Handle MBM hot swap. Power that is on is left on, power that is off is left off.
Group Formation Majority / Minority Replicated Data Sync	Normal group processing, new group is formed	New Group is initiated. A group forms and a leader is selected.	
		If there was not a previous majority group, then the replicated database is marked invalid.	
		If the new group is a minority, mark the database read-only.	
		If the new group is a majority, request the database and any pending updates from all members who were previously joined to the MaxPrevMajorityGroup.	
		Apply the longest list of updates to the corresponding database copy and send the new initial replicated database to all members. All members mark the database as valid.	
		If the new group is a majority and there was no previous majority group, then clear the powerup_complete flag.	
		If the new group is a majority and the powerup_complete flag is set, then proceed to the Hardware Init phase. Else, proceed to the Operational phase.	Minority groups remain in this phase
Hardware Init	Return to forming a new group and re-run init	Poll CMMs to determine CPU module population details within each 8P backplane. This initializes the list of available resources.	
		The Leader computes a routable configuration for each partition based upon the requested and available CPU resources.	
		The leader decides to power up the partitions. It commands all MBMs, PBMs, and CMMs to power up. Upon completion, the leader obtains the results from each of these commands and adjusts the list of available resources accordingly.	
		The partition coordinators start XSROM testing on all CPUs for memory.	
		The PMU Server initiate IP cable testing between 8P backplanes and IO cable testing between 8P backplanes and I/O crates. The results are used to recalculate routing and assign I/O to partitions.	
		The partition coordinators initiate XSROM tests for I/O and routing. The results are used to recalculate routing and adjust the list of I/O resources.	
		The partition coordinators initiate remote memory testing between CPUs in the same partitions.	
		The partition coordinators initiate interrupt testing between CPUs in the same partitions.	
S/W Load (SRM + O/S)	New Groups are treated as hot-adds	The leader sets the powerup_complete flag to true and proceeds to the S/W Load phase.	
		The partition coordinators elect a primary EV7 in each partition. They command all secondaries to spin on RBOX_SCRATCH and initiate loading of the SRM firmware on the primary.	
		The SRM firmware commands the secondary CPUs to join by writing RBOX_SCRATCH. The primary EV7 completes all I/O initialization.	
Operational	New Groups are treated as hot-adds	If the SRM auto_action environment variable is set to BOOT, the operating system boot is attempted on the partition.	
		Server management requests from the primary EV7 in each partition are handled by the CMMs / MBMs / PBMs.	
		If a new group has caused a change in the CPU, Memory, or I/O resources, notify the primary EV7 in each affected partition.	
		If a new resource has been pre-allocated to a partition, then the partition coordinator takes the steps necessary to probe the IP or IO links to the new resource (CPU or I/O drawer).	

Marvel System Powerup Flow with Group relationship

Fig. 21

Capability	via private LAN	via FPGA
Virtual console terminal access	Yes	No
Firmware updates	Yes	No
Load/Disable Test firmware	Yes	No
Live configuration change <sup>1</sup>	No	Yes
Writing SRM environment vars <sup>2</sup>	No	Yes
Unsolicited notification of alerts	Yes	No
Store PCI Slot information <sup>2</sup>	No	Yes
All others	Yes	Yes

Fig. 22



*PMU Server Block Diagram*

Fig. 23



Command Group	Commands Received	Class	PMU Server Handling Method
System Discovery	Get MBM / PBM CONFIGURATION	Forward	Commands are forwarded to the MBM or PBM addressed in the message header. Responses are forwarded back to the PMU.
	GET PCI SLOT INFO		
	GET PARTITION DATABASE	Direct	The PMU Server derives the response from his local copy of the Partition Database.
	GET OWN PARTITION NUMBER		
	GET SYSTEM TOPOLOGY	Direct	The PMU Server keeps track of the applications making this multi phase request until the last entity has been requested. The entity number in the request is used to index into a list composed of the combination of group members and partition database. The IP addresses, parent relationship and partition number is derived from these values found in NVRAM. If the group members or partition database changes before the last entity is requested, an error response is returned on the next request.
	SET PCI SLOT INFO		
Partition Control	ALL COMMANDS OF GROUP	Forward	All commands in this group that contain a partition number are forwarded to the MBM running the appropriate partition coordinator. The exceptions are Read State of OCP switches, OCP Switch assignment and Power On/Off commands that are simply forwarded to their destination.
EV7 Setup	REQUEST EV7 START TEST	Forward	This command is forwarded to the destination EV7.
Cable Test Group	GET CABLING CONFIGURATION	Direct	The PMU Server responds with the contents of the Cable Database that he composed during Initialization or was requested via Reconfigure Cabling.
	RETEST CABLE CONFIGURATION	Complex	The PMU Server re-initiates the test of all IP and IO cabling making use of the commands Get MBM IP Cabling and Get PBM IP Cabling.
	SET CABLE TEST SIGNAL	Complex	The PMU Server ensures that there are no other on-going cabling requests and forwards these commands to the PBM or MBM in the destination field and returns the response to the PMU.
	GET CABLE TEST SIGNAL		
Virtual Console	GET TELNET IP ADDRESS/PORT	Direct	PMU Server determines the primary MBM's IP Address and the socket port.
Firmware Load and Upgrade, Environmental Retrieval, FRU Data, Error Logging, Miscellaneous		Forward	All commands in these groups are forwarded to the CMM, PBM or MBM in the destination field and the response returned to the PMU.
Date/Time		Forward Direct	The PMU Server allows Base Time Gets and Sets from all PMUs but Delta Time Sets and Gets can only come from Partition Primary EV7s. The requests are forwarded to the MBM being addressed.
Miscellaneous	GET/SET KNOB READ/WRITE BLOCK DATA	Forward	These requests are forwarded to the destination for processing.

PMU Server Received Command Handling


Fig. 24

Command Group	Commands Received	PMU Server Handling Method
System Discovery	Get MBM/PBM CONFIGURATION	
	GET PARTITION DATABASE	
Cable Testing	SEND CABLE ID RECEIVE CABLE ID GET MBM IP CABLING GET PBM IP CABLING	These commands are issued in response to a RETEST CABLE CONFIGURATION request. The process is discussed in section Error! Reference source not found., Error! Reference source not found.
Error Logging Group	ERROR REPORTING	The PMU Server knows the IP address of client PMUs and distributes the alerts to each PMU.
Miscellaneous	DISTRIBUTE DHCP LEASE DATA	The DHCP server runs on the PMU Server and keeps track of the DHCP clients. For failover purposes, this data is replicated on all nodes. See section Error! Reference source not found. Error! Bookmark not defined..

*PMU Server Originating Commands*

**Fig. 25**

# Show Configuration



Marvel System Configuration used in this example

Fig-26

PMU	MBM PMU Server DHCP Server	CMM	EV70	EV71	PBM	The PMU's PC connects to the LAN and requests an IP address
PMU	MBM PMU Server DHCP Server	CMM	EV70	EV71	PBM	The MBM is running a DHCP server and provide it a lease on a DHCP address.
PMU	MBM PMU Server DHCP Server	CMM	EV70	EV71	PBM	The PMU application when initializing issues the GET SYSTEM TOPOLOGY command starting at 0. The command is issued to th PMU Server which is a predetermined address
PMU	MBM PMU Server DHCP Server	CMM	EV70	EV71	PBM	Entity 0, the data for the MBM is returned.
PMU	MBM PMU Server DHCP Server	CMM	EV70	EV71	PBM	PMU sends a GET MBM CONFIGURATION to the MBM and picks up information, like the RIMM population.
PMU	MBM PMU Server DHCP Server	CMM	EV70	EV71	PBM	The PMU Server task forwards the command to the MBM SM protocol servicing task. It returns information on the CPUs that is has gathered previously.
PMU	MBM PMU Server DHCP Server	CMM	EV70	EV71	PBM	The PMU issues the GET SYSTEM TOPOLOGY for entity 1
PMU	MBM PMU Server DHCP Server	CMM	EV70	EV71	PBM	Entity 1, the CMM, is returned.

Show Config Flow Diagram (Part 1)

Fig-27






Fig. 29 Show Configuration Flow Diagram ( Part 3 )

Configuration of Marvel at: 5/22/00 08:30:05

MBM Rack 3-01: Part No=A1234567; Revision=32; Serial No=1233456789; MFGDate=040101; 3 Errors

CMMIO: Part No=C113566; Revision=01; Serial No=11335577

EV70: Partition 8/0; GTL Voltage=1.5; 5v=4.9; Temp=85F; Part No=E7-435; Revision=5; Serial No=9876543; MFGDate=101100

EV71: Partition 8/0; GTL Voltage=1.0; 5v=5.0; Temp=45F; Part No=E7-435; Revision=2; Serial No=9876530; MFGDate=092100

RIMM0=256MB; Part No=RA03-256; Revision=1; Serial No=000123456; MFGDate=070199

RIMM1=256MB; Part No=RA03-256; Revision=1; Serial No=000123457; MFGDate=070199

48V Power Supplies: 1-Operational; 2-Missing; 3-Operational; 4-Off

FAN1=340RPM(minimal=200);

PBM Rack 6-02: Part No=B1234567; Revision=32; Serial No=1233456790; MFGDate=040100; 0 Errors

Power Supply: 1-Operational; 5v=5.0; 5v=5.1; 12v=11.99; 3.3v=3.1; Temp=98F

FAN1=286rpm(minimal=100); FAN2=330rpm(minimal=100); Part No=PA003; Revision=01; Serial No=SS2358


IO Drawer: Partition 8; Part No=CP000IO1; Revision=07; Serial No=IO2345

PCI slot 3: class=01; subclass=04; deviceid=0701; vendorid=0809; intpin=A; irq=5

PCI slot 5: class=02; subclass=03; deviceid=0c00; vendorid=a312; intpin=D; irq=9

Show Config Sample Output

Fig. 30



Partition Request Sources  
Fig-31

Requests Received	Class	Partition States	Handling Methods	Reference Flow
Move EV7s to Partition Remove EV7s from Partition	Complex	Partition Running OS	Check the proper cabling of a newly formed hard partition or additions to an existing partition. Determine memory and routability. Distribute the requests on the TRAIN to update volatile Databases.	
Assign Memory or IO to Sub Partition	Trained			
Set Partition State Attributes	Trained			
Switch Primary EV7	Complex	Partition Running OS	Distribute the requests on the TRAIN to update volatile Database.	
Assign Sub Partitions	Trained			
Assign Memory or IO to Sub-partition	Trained			
Add EV7or Delete EV7 to/from Running Partition	Complex	Partition Running OS	Cable testing is performed to determine proper connections ; A Quiesce request is made to all EV7s in the partition; new Rconfig/Cconfig requests are sent to all EV7s and if acceptable Continue is sent to the EV7s. If an error is found in routing new Rconfig/Cconfig computations are attempted and sent to the affected EV7s.	Figure 16
Save Partition Assignment	Trained	Don't Care	Send the save command on the train so that all copies of volatile database for the partition can be copied to non-volatile.	Figure 9
Reset Partition	Complex	Partition Reset in Progress or Partition running OS	Pulse Reset on all EV7s in partition, Reload SRM, XSROM on all EV7s, reconfigure Routing, send Rconfig/Cconfig to all EV7s and if no errors, Load SRM to primary.	Figure 11
		Partition Powered Off	Return Error	
Power Off Partition	Complex	Partition Reset in Progress or Partition running OS	If Dual EV7 in partition or EV7 in free pool, send Power Off EV7s to each such CMM in partition. Power off PCI Drawer on PBMs that have all IO7 risers in partition. If power is off for all CMMs in a cabinet of MBMs, power off the power supplies in the cabinet.	
		Partition Powered Off or request made to sub partition	Return Error	
Power On Partition	Complex	Partition Reset in Progress or Partition running OS	Return Error	
		Partition Powered Off	Turn Power on to any Power Supplies that are off and under control of Cabinets that have EV7s assigned to our partition. Power up PCI drawers for PBMs that have IO7s in our partition. Power up Dual EV7s on CMMs that have EV7s in our partition. Continue like the reset process.	
Halt Partition	Forwarded	Partition Reset in Progress or Partition running OS	Send Halt On to primary Ev7 of partition.	
		Partition in Halt State or Partition Power off	Return Error	
Disable Halt Partition	Forwarded	Partition Reset in Progress or Partition running OS	Return Error	
		Partition in Halt State or Partition Power off	Send Halt Off to primary Ev7 of partition	
Store Environment Variables	Trained	Partition running OS	This causes a distribution of the SRM environment variables to all peers	Figure 34
Get Environment Variables	Direct	Partition running OS	Return local copy of all SRM environment variables	

*Partition Coordinator Handling of Requests*

**Fig. 32**




Commands Issued	Partition States	Handling Methods	Reference Flow
Train Full	Any		
EV7 Quiesce	Partition Reset in Progress	CMM facilitates	Figure 17, Figure 20
Config Rbox/Cbox	Partition Reset in Progress	CMM facilitates	Figure 17, Figure 20
EV7 Reset	Any	CMM facilitates	Figure 15
EV7 Start Test	Partition Reset in Progress	CMM facilitates	Figure 16, Figure 18
EV7 Halt	Any	CMM facilitates	
Load Image	Partition Reset in Progress	CMM facilitates	Figure 15, Figure 20
Set Partition State	Partition Reset in Progress	CMM facilitates	Figure 15, Figure 16, Figure 17, Figure 18, Figure 20, Figure 21
Power On/Off	Any	CMM, MBM, and PBM facilitates	

*Partition Coordinator Commands Issued*


Fig. 33

001630" 63163960



*Partition State Diagram*

Fig. 34



*Inputs and Outputs of Router algorithm*

Fig. 35

### *Routing Glossary*

**Primary dimension:** one of EAST-WEST or NORTH-SOUTH. This choice is the same for all EV7s.

**Secondary dimension:** the other way.

**Dimension-order routing:** the shortest path connecting two nodes which proceeds first along the primary dimension and then along the secondary.


**Adaptive routing:** the collection of paths advancing node-to-node in the same primary and secondary directions as the dimension-order routing. At each intermediate node it must be possible to advance in either direction until the dimension coordinate in a direction matches that of the destination.

**Initial hop:** a routing option which allows a hop from the source node in any direction to an adjacent node. This option allows some connection of nodes in imperfect meshes.


**SRC routing:** another deadlock-free routing method in which travel proceeds first along the secondary dimension.

Fig. 36 Routing Glossary


007630-371000




Partition Coordination  
Fig. 37




At initial poweron, the unconfigured Marvel system is configured to have all resources in a single subpartition. The global free pool (HP 255) is empty.



The user creates hard partition 1 (HP1) with subpartition 0 (SP 0). The partition free pool (SP 255) is created automatically.



The user deletes several EV7s from the hard partition (HP 0) and they migrate to the global free pool (HP 255).












The user can move the EV7s into the new partition, (HP 1,SP 0). By default the IO7s are assigned to the same partition as the EV7 to which it belongs.

Creating a Hard Partition Block Flow

Fig. 38












	PMU Server	All MBMs/PBMs	The PMU gathers information about the system configuration.
	PMU Server	All MBMs/PBMs	The user associates a hard partition & sub partition with one or many EVs.
	PMU Server	All MBMs/PBMs	<b>MOVE EV7 TO PARTITION</b> stored in volatile database
	PMU Server	All MBMs/PBMs	The data is distributed to all MBMs and PBMs on the train with a <b>FULL TRAIN</b> transmission.
	PMU Server	All MBMs/PBMs	The PMU Server replies successfully after all the MBMs/PBMs have the update.
	PMU Server	All MBMs/PBMs	The user associates each IO7 to a hard partition & sub partition
	PMU Server	All MBMs/PBMs	<b>ASSIGN IO7 TO SUB PARTITION</b> stored in volatile database
	PMU Server	All MBMs/PBMs	The data is distributed to all MBMs and PBMs on the train with a <b>FULL TRAIN</b> transmission.
	PMU Server	All MBMs/PBMs	The PMU Server replies successfully after all the MBMs/PBMs have the update.

REPEAT

Creating a New Partition Flow Diagram ( Part 1 of 2)

Fig. 40

	PMU Server	All MBMs/PBMs	The user associates memory with the hard partition & sub partition
	PMU Server	All MBMs/PBMs	<b>ASSIGN MEMORY TO SUB PARTITION</b> stored in volatile database
	PMU Server	All MBMs/PBMs	The data is distributed to all MBMs and PBMs on the train with a <b>FULL TRAIN</b> transmission.
	PMU Server	All MBMs/PBMs	The PMU Server replies successfully after all the MBMs/PBMs have the update.
	PMU Server	All MBMs/PBMs	The user indicates that he/she is done setting up the partition.
	PMU Server	All MBMs/PBMs	<b>SAVE PARTITION ASSIGNMENTS</b>
	PMU Server	All MBMs/PBMs	The data is distributed to all MBMs and PBMs on the train with a <b>FULL TRAIN</b> transmission.
	PMU Server	All MBMs/PBMs	The PMU Server replies successfully after all the MBMs/PBMs have the update.
	PMU Server	All MBMs/PBMs	Done. The user can now start the partition.

REPEAT

Creating a New Partition Flow Diagram ( Part 2 of 2 )

Fig. 41



## RESET STATE

PMU	PMU Server	Group Leader	MBMs	CMMs	EV7s	After a group formation, the leader reconciles the partition database and starts up a partition coordinator for each partition. The PC is started on the lowest MBM id in the partition.
PMU	PMU Server	Part. Coord	MBM	CMMs	EV7s	The PC gathers information about the current state of the partition. Each MBM in the partition is queried for state of the CMMs with the <b>GET MBM CONFIGURATION</b> request
PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	Each CMM in the partition is queried with the <b>GET CMM STATE</b> command.
PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	Each CMM returns the status of the EV7s it controls.
PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	The MBM assembles the data from all the CMMs into the reply to the <b>GET MBM CONFIGURATION</b>
PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	Each PBM in the partition is queried for state of the CMMs with the <b>GET PBM CONFIGURATION</b> request
PMU	PMU Server	Part. Coord	PBMs	CMMs	EV7s	The PBMs reply with the IO7 configuration.
PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	The P.C. sets the state of the partition to <b>RESET-IN-PROGRESS</b> with the <b>SET PARTITION STATE</b> .
PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	The command goes to all MBMs in the entire system, not just the ones in this partition. The MBMs record the state. See the "MBM Start Partition State Diagram."
PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	The Part. Coord. determines the PID of every EV7 in the hard partition and assigns a PID. The CMM is sent a <b>CONFIG RBOX/CBOX</b> packet with this PID value and defaults for router tables.
PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	The CMM stores the PID information in ram that is accessible by the EV7 for later retrieval.
PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	The Partition Coordinator performs a partition reset by issuing, individually, a <b>PULSED RESET</b> to each EV7 in the partition.
PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	The CMM intercepts this command and performs the <b>PULSED RESET</b> on the EV7s. The CMM facilitates the FPGA load and SROM load which then loads the XSROM the the <b>LOAD XSROM IMAGE</b> packet.

Partition Start Flow Diagram ( Reset State )

Fig. 42

## DIAGNOSTIC STATE











Figure 43 Partition Start Flow Diagram, Diagnostic State


























## CONFIGURE ROUTER

 PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	The P.C. sets the state of the partition to <i>CONFIGURE-ROUTER-IN-PROGRESS</i> with the <b>SET PARTITION STATE</b> .
 PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	The command goes to all MBMs in the entire system, not just the ones in this partition. The MBMs record the state. See the "MBM Start Partition State Diagram."
 PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	<b>QUIESCE PARTITION</b> is sent to all EV7s in the partition. In this example, the EV7s are in XSROM, which is already a quiesced state.
 PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	This command is serviced by the CMM and performs the necessary steps to have the EV7 (still running XSROM) configure the router.
 PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	<b>CONFIG RBOX/CBOX</b> is sent to all EV7s in the partition
 PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	This command is serviced by the CMM and performs the necessary steps to have the EV7 (still running XSROM) configure the router.
 PMU	PMU Server	Part. Coord	MBMs	CMMs	EV7s	Continued on next flow

*Partition Start Flow Diagram (Configure Router)*

Fig. 44

## CONTINUE PARTITION and PARTITION RUNNING

	PMU Server		MBMs	CMMs	EV7s	The P.C. sets the state of the partition to <i>CONTINUE-PARTITION-IN-PROGRESS</i> with the <b>SET PARTITION STATE</b> .
	PMU Server	Part. Coord		CMMs	EV7s	The command goes to all MBMs in the entire system, not just the ones in this partition. The MBMs record the state. See the "MBM Start Partition State Diagram."
	PMU Server		MBMs	CMMs	EV7s	The non-primary EV7s are given an <b>EV7 START TEST</b> that sets them waiting for a flag to jump into the running image.
	PMU Server	Part. Coord	MBMs			This command is forwarded by the CMM and EV7s are now ready and waiting
	PMU Server		MBMs	CMMs	EV7s	The partition is now completely configured. All EV7s are running XSROM. The P.C. now directs the primary EV7 to start the SRM console via the <b>LOAD IMAGE</b>
	PMU Server	Part. Coord	MBMs			The CMM intercepts this command and performs the necessary operations to get the Primary EV7 loaded and running.
	PMU Server	Part. Coord	MBMs	CMMs		The Primary EV7, writes a flag in each of the other EV7s, indicating that they should jump into the running image.
	PMU Server		MBMs	CMMs	EV7s	The P.C. sets the state of the partition to <i>PARTITION RUNNING</i> with the <b>SET PARTITION STATE</b> .
	PMU Server	Part. Coord		CMMs	EV7s	The command goes to all MBMs in the entire system, not just the ones in this partition. The MBMs record the state. See the "MBM Start Partition State Diagram."
	PMU Server		MBMs	CMMs	EV7s	The P.C. notifies the PMU server in the system that the partition has been started.
		Part. Coord	MBMs	CMMs	EV7s	The PMU Server notifies all the connected PMUs that the partition has been started.
	PMU Server	Part. Coord	MBMs	CMMs	EV7s	The End

Partition Start Flow Diagram ( Running )

Fig. 45


OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s	OS uses SRM callback to issue <b>ADD EV7 TO RUNNING PARTITION</b> listing EV7#4 and EV7#5 and Hard Partition #2 Sub #1. The PMU Server handles the request.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s	The PMU Server knows the address of the partition coordinator and forwards the <b>ADD EV7 TO RUNNING PARTITION</b> to the appropriate part. coord.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s	The PMU Server issues a <b>SET PARTITION STATE</b> to <b>PARTITION CHANGE IN-PROGRESS</b> to all MBMs via the train mechanism.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	All MBMs/PBMs track this state in their replicated data base. PMU Server access is limited until the partition change completes.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	The Part. Coord. directs the PMU Server to <b>RECONFIGURE CABLING</b> to get the current status of the cables
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	The PMU Server coordinates the cable testing. Details are in a later section of this document. Results are stored at the PMU Server. <b>GET MBM IP CABLING, GET PBM IO CABLING, SEND CABLE ID, RECEIVE CABLE ID</b>
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	Upon successful completion of the cable test, the Part. Coord. issues a <b>GET CABLING CONFIGURATION</b> to the PMU Server to get the latest cable data.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	The PMU Server responds with the current cable connectivity data base.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	The Part. Coord validates the cable connectivity. If okay <b>ADD EV7 TO RUNNING PARTITION</b> is distributed to all MBMs/PBMs on the LAN via the train mechanism.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	All MBMs/PBMs modify their replicated data bases to track this change to the free pool and to partition #2.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7#4 EV7#5	<b>PULSE EV7 RESET</b> is directed at EV7#4 and EV7#5 (command issued to the CMM)
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7#4 EV7#5	EV7#4 and EV7#5 are reset. The CMM facilitates the SROM load. The XSROM is started with the <b>LOAD IMAGE</b> .
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	continues on next figure

Add EV7 Flow Diagram (Part 1)

Fig. 46 A


OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	The Part. Coord. calculates the routability of the proposed new configuration. If there is a routing error the command finishes with error. When routing is successful, a SET PARTITION STATE to CONFIG-ROUTE-IN-PROGRESS
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	All MBMs receive the SET PARTITION STATE via the train mechanism and set their databases to indicate that HP#2 is in the CONFIG-ROUTE-IN-PROGRESS state
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	When the train completes, the Part. Coord. commands each EV7 in hard partition #2, individually, to QUIESCE.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	QUIESCE is received at the CMMs in the partition and they take actions to quiesce the EV7. EV#4 and EV#5 are in XSROM and do not have to be quiesced.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	CONFIG RBOX/CBOX is sent to all EV7s in the partition, which includes EV#4 and EV#5 which are in XSROM.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CMMs in HP#2	EV7s in HP#2	CONFIG RBOX/CBOX is received at the CMMs and they direct the EV7 to config the RBOX and the CBOX.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CCMs in HP#2M	EV7s in HP#2	SET PARTITION STATE to CONTINUE-PARTITION-IN-PROGRESS. This is distributed via the train mechanism.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CCMs in HP#2M	EV7s in HP#2	All MBMs/PBMs track the state of the partition in their replicated data base.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CCMs in HP#2M	EV7s in HP#2	CONTINUE PARTITION is sent to all EV7s in the partition, including EV7#4 and EV7#5.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CCMs in HP#2M	EV7s in HP#2	All MBMs/PBMs track the state of the partition in their replicated data base.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CCMs in HP#2M	EV7s in HP#2	SET PARTITION STATE to PARTITION RUNNING is issued on the train.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CCMs in HP#2M	EV7s in HP#2	All MBMs/PBMs track the state of the partition in their replicated data base.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CCMs in HP#2M	EV7s in HP#2	The Part. Coord. notifies the PMU Server that the ADD EV7 TO PARTITION is done.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CCMs in HP#2M	EV7s in HP#2	The PMU Server responds to the original ADD EV7 to PARTITION.
OS via SRM	PMU Server	Part. Coord HP#2	MBMs PBM	CCMs in HP#2M	EV7s in HP#2	The End.

Fig. 46B



*Add vs Move*


Fig. 47



*Destroying a soft partition*

Fig. 48







| *Destroying a hard partition*

Fig. 49


This flow is an example of SM protocol activity when a CPU module fails. The entire configuration is one partition, and the failing CPU module is not the primary.

The operating system does crash, and is restarted. The failed CPU module is replaced and the original complete configuration is restored.









EV7 Failure/Replace Flow Diagram (Part 1)

Fig. 50




### EV7 Failure/Replacement Flow Diagram ( Part 2 )

 PMU	MBM1	MBM2	PBM0	New MBM3	The Marvel system is running with MBM1, MBM2, and MBM3. A new 8P is rolled up and plugged into the SM LAN and powered up.
 PMU	MBM1	MBM2	PBM0	New MBM3	MBM3 recognizes that it is joining a already formed group of processors and has a different membership list than the group it has joined. MBM3 goes its a passive listening state.
 PMU	MBM1	MBM2	PBM0	New MBM3	The New MBM3 is not defined as a member in the old group, so it is isolated from the group.
 PMU	MBM1	MBM2	PBM0	New MBM3	The operator issues a <b>SET MEMBERSHIP CONFIGURATION</b> to the PMU to change the membership list from {MBM1,MBM2,PBM0} to {MBM1,MBM2,MBM3,PBM0}. The PMU broadcasts this to the entire LAN.
 PMU	MBM1	MBM2	PBM0	New MBM3	All LAN members receive this membership list and change their expected membership data. Then they all participate in new group formations.
 PMU	MBM1	MBM2	PBM0	New MBM3	The group is formed MBM3 is now an active member.

*Set Membership Configuraton Flow Diagram*


Fig. 52



*IP Cable Configuration Block Diagram*


Fig. 53






IO7 Cabling Block Diagram

Fig. 55



Get Cable Configuration Block Diagram

Fig. 56




*IP Cable Addition/Deletion Block Diagram*

Fig. 57



Fig. 58



*Proxy Forwarding Block Diagram*

Fig. 59















Fig. 60

GMM	EV7	COM1 Port	COM2 Port
1	1	323	324
1	2	325	326
2	1	327	328
2	2	329	330
3	1	331	332
3	2	333	334
4	1	335	336
4	2	337	338

*Virtual Terminal Telnet*

Fig. 61

## Virtual Terminal Session

	PMU Server	Telnet Svr for Pri EV7	MBMs	CMMs	EV7s	The PMU platform is plugged into an available port on the SM LAN
	PMU Server	Telnet Svr for Pri EV7	MBMs	CMMs	EV7s	The PMU sends a <b>Get Telnet IP Address/Port</b> request to PMU Server for the address of the telnet server for the primary EV7 for a partition
	PMU Server	Telnet Svr for Pri EV7	MBMs	CMMs	EV7s	PMU Server gives to the PMU the address of the telnet server for the primary EV7 ( <b>Get Telnet IP Address/Port</b> response packet)
	PMU Server	Telnet Svr for Pri EV7	MBMs	CMMs	EV7s	User starts a telnet session on the PMU using the telnet server address from previous step
	PMU Server	Telnet Svr for Pri EV7	MBMs	CMMs	EV7s	Telnet server passes characters to Virtual Console task on MBM for Primary EV7
	PMU Server	Telnet Svr for Pri EV7	MBMs	CMMs	EV7s	MBM for Primary EV7 passes characters to CMM for Primary EV7 using <b>PUT_CHAR</b> packet
	PMU Server	Telnet Svr for Pri EV7	MBMs	CMMs	EV7s	CMM strips off IP addressing info and passes the character to Primary EV7 through the virtual console uart registers
	PMU Server	Telnet Svr for Pri EV7	MBMs	CMMs	EV7s	Primary EV7 responds with characters back to CMM
	PMU Server	Telnet Svr for Pri EV7	MBMs	CMMs	EV7s	CMM envelops character in <b>PUT_CHAR</b> protocol packet and gives to MBM
	PMU Server	Telnet Svr for Pri EV7	MBMs	CMMs	EV7s	MBM Virtual Console task passes character to Telnet server
	PMU Server	Telnet Svr for Pri EV7	MBMs	CMMs	EV7s	Telnet server passes character to Telnet session on PMU


*Virtual Terminal Flow Diagram*

Fig. 62

1978	1979	1980	1981	1982
1983	1984	1985	1986	1987
1988	1989	1990	1991	1992
1993	1994	1995	1996	1997
1998	1999	2000	2001	2002
2003	2004	2005	2006	2007
2008	2009	2010	2011	2012
2013	2014	2015	2016	2017
2018	2019	2020	2021	2022
2023	2024	2025	2026	2027
2028	2029	2030	2031	2032
2033	2034	2035	2036	2037
2038	2039	2040	2041	2042
2043	2044	2045	2046	2047
2048	2049	2050	2051	2052
2053	2054	2055	2056	2057
2058	2059	2060	2061	2062
2063	2064	2065	2066	2067
2068	2069	2070	2071	2072
2073	2074	2075	2076	2077
2078	2079	2080	2081	2082
2083	2084	2085	2086	2087
2088	2089	2090	2091	2092
2093	2094	2095	2096	2097
2098	2099	2100	2101	2102
2103	2104	2105	2106	2107
2108	2109	2110	2111	2112
2113	2114	2115	2116	2117
2118	2119	2120	2121	2122
2123	2124	2125	2126	2127
2128	2129	2130	2131	2132
2133	2134	2135	2136	2137
2138	2139	2140	2141	2142
2143	2144	2145	2146	2147
2148	2149	2150	2151	2152
2153	2154	2155	2156	2157
2158	2159	2160	2161	2162
2163	2164	2165	2166	2167
2168	2169	2170	2171	2172
2173	2174	2175	2176	2177
2178	2179	2180	2181	2182
2183	2184	2185	2186	2187
2188	2189	2190	2191	2192
2193	2194	2195	2196	2197
2198	2199	2200	2201	2202
2203	2204	2205	2206	2207
2208	2209	2210	2211	2212
2213	2214	2215	2216	2217
2218	2219	2220	2221	2222
2223	2224	2225	2226	2227
2228	2229	2230	2231	2232
2233	2234	2235	2236	2237
2238	2239	2240	2241	2242
2243	2244	2245	2246	2247
2248	2249	2250	2251	2252
2253	2254	2255	2256	2257
2258	2259	2260	2261	2262
2263	2264	2265	2266	2267
2268	2269	2270	2271	2272
2273	2274	2275	2276	2277
2278	2279	2280	2281	2282
2283	2284	2285	2286	2287
2288	2289	2290	2291	2292
2293	2294	2295	2296	2297
2298	2299	2300	2301	2302
2303	2304	2305	2306	2307
2308	2309	2310	2311	2312
2313	2314	2315	2316	2317
2318	2319	2320	2321	2322
2323	2324	2325	2326	2327
2328	2329	2330	2331	2332
2333	2334	2335	2336	2337
2338	2339	2340	2341	2342
2343	2344	2345	2346	2347
2348	2349	2350	2351	2352
2353	2354	2355	2356	2357
2358	2359	2360	2361	2362
2363	2364	2365	2366	2367
2368	2369	2370	2371	2372
2373	2374	2375	2376	2377
2378	2379	2380	2381	2382
2383	2384	2385	2386	

### Set Base Time Flow Diagram

**Fig. 63**



*DHCP Block Diagram*

Fig. 64

<i>Content</i>	<i>TFTP Filename</i>	<i>Block Size</i>	<i>Sector Start(offset)</i>	<i>Sector End</i>
MBM/PBM Firmware	"mbmfw", "pbmfw"	2 MB	0	7
CMM, CMM_FSL, FPGA, SRAM, XSROM Firmware	"cmmfw", "cmmfsl", "cmmfpga", "sromfw", "xsromfw"	0.5 MB	8(0,tbd,tbd,tbd,tbd,tbd)	9
Error Logs		1 MB	10	13
MBM/PBM FSL Firmware	"mbmfsl", "pbmfsl"	0.5 MB	14	15
NVRAM – partition database		0.75 MB	16	18
SRM Firmware	"srmfw"	2 MB	20	27
FPGA loaded by PBM on PCI Drawers	"pbmfpga"	0.25MB	28	28
MBM/PBM Boot[if required by HW]		0.25	19(0,0x30000)	19

Flash Layout


Fig. 65



Byte Offset	Value
0.. 7	0x010100005500aaff
8.. 19	Image Revision in ASCII
20.. 23	Vendor String in ASCII (CPQ)
24.. 31	Module ID in ASCII (SRMFW,MBMFW,MBMFSL,CMMFW,CMMFSL,SROMFW,XSROMFW,CMMFPGA)
32.. 35	Firmware Type in ASCII (ALPH, X86)
36.. 43	0x00
44.. 47	Code Length in bytes
48.. 59	ROM Object Name (FW,FSL,SROM,XSROM,FPGA)
60.. 63	0x11223344


*Image Header*

Fig. 66



*SRM Environment Vars Flow Diagram*

Fig. 67



### Firmware Load and Upgrade Block Diagram

Fig. 68






ERROR ENTRY DATA										
Size (dec)	Start (hex)	End (hex)	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4	0	3	Entry Number							
1	4	4	Severity Level							
1	5	5	Entity in Error							
1	6	6	Instance							
2	7	8	Error Code							
16	9	18	Serial Number							
n	19	n+19	Variable Data							
<b>Entry Number</b>			IP address of CMM, MBM, PBM, or EV7 that encountered the error.							
<b>Severity Level</b>			Informational=0; Warning=1; Error=2;							
<b>Entity in Error</b>			The device code for the device in error (e.g. CMM, RIMM, EV7, Thermal, Volatage)							
<b>Instance</b>			The instance of the entity							
<b>Error Code</b>			Error enumeration or index into a set of text messages							
<b>Serial Number</b>			Identifying address where the error occurred.							
<b>Variable Data</b>			Additional data specific to this error code.							

*Error Entry Data Format*

**Fig. 71**



Error Reporting Flow Diagram

Fig. 72





	1978	1979	1980	1981	1982	1983	1984	1985	1986	1987	1988	1989	1990	1991	1992	1993	1994	1995	1996	1997	1998	1999	2000	2001	2002	2003	2004	2005	2006	2007	2008	2009	2010	2011	2012	2013	2014	2015	2016	2017	2018	2019	2020	2021	2022	2023	2024	2025	2026	2027	2028	2029	2030	2031	2032	2033	2034	2035	2036	2037	2038	2039	2040	2041	2042	2043	2044	2045	2046	2047	2048	2049	2050	2051	2052	2053	2054	2055	2056	2057	2058	2059	2060	2061	2062	2063	2064	2065	2066	2067	2068	2069	2070	2071	2072	2073	2074	2075	2076	2077	2078	2079	2080	2081	2082	2083	2084	2085	2086	2087	2088	2089	2090	2091	2092	2093	2094	2095	2096	2097	2098	2099	2100	2101	2102	2103	2104	2105	2106	2107	2108	2109	2110	2111	2112	2113	2114	2115	2116	2117	2118	2119	2120	2121	2122	2123	2124	2125	2126	2127	2128	2129	2130	2131	2132	2133	2134	2135	2136	2137	2138	2139	2140	2141	2142	2143	2144	2145	2146	2147	2148	2149	2150	2151	2152	2153	2154	2155	2156	2157	2158	2159	2160	2161	2162	2163	2164	2165	2166	2167	2168	2169	2170	2171	2172	2173	2174	2175	2176	2177	2178	2179	2180	2181	2182	2183	2184	2185	2186	2187	2188	2189	2190	2191	2192	2193	2194	2195	2196	2197	2198	2199	2200	2201	2202	2203	2204	2205	2206	2207	2208	2209	2210	2211	2212	2213	2214	2215	2216	2217	2218	2219	2220	2221	2222	2223	2224	2225	2226	2227	2228	2229	2230	2231	2232	2233	2234	2235	2236	2237	2238	2239	2240	2241	2242	2243	2244	2245	2246	2247	2248	2249	2250	2251	2252	2253	2254	2255	2256	2257	2258	2259	2260	2261	2262	2263	2264	2265	2266	2267	2268	2269	2270	2271	2272	2273	2274	2275	2276	2277	2278	2279	2280	2281	2282	2283	2284	2285	2286	2287	2288	2289	2290	2291	2292	2293	2294	2295	2296	2297	2298	2299	2300	2301	2302	2303	2304	2305	2306	2307	2308	2309	2310	2311	2312	2313	2314	2315	2316	2317	2318	2319	2320	2321	2322	2323	2324	2325	2326	2327	2328	2329	2330	2331	2332	2333	2334	2335	2336	2337	2338	2339	2340	2341	2342	2343	2344	2345	2346	2347	2348	2349	2350	2351	2352	2353	2354	2355	2356	2357	2358	2359	2360	2361	2362	2363	2364	2365	2366	2367	2368	2369	2370	2371	2372	2373	2374	2375	2376	2377	2378	2379	2380	2381	2382	2383	2384	2385	2386	2387	2388	2389	2390	2391	2392	2393	2394	2395	2396	2397	2398	2399	2400	2401	2402	2403	2404	2405	2406	2407	2408	2409	2410	2411	2412	2413	2414	2415	2416	2417	2418	2419	2420	2421	2422	2423	2424	2425	2426	2427	2428	2429	2430	2431</
--	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	--------

Line	12345678901234567890
1	< Overall Progress >
2	< Current State >
3	< Location within State >
4	< Error Message >

### OCP Template

Fig. 74

0	1	3	4	5	6	X
P		PP	F	P		
1	1	0	1	1	1	1
EV 5 RIMM 2 Parity						


*OCP 8P Example*

Fig. 75

0	1	3	4	5	6	X
P		PP	F	P		
1	1	0	1	1	1	1
Power		Halt				
Reset						

*OCP Button Label Example*

Fig. 76



*OCP Switches Block Diagram*

Fig. 77

Command	Purpose	Process
SET ATTENTION INDICATOR	Light, Extinguish LED at MBM, PBM, CMM or Cabinet	Take action according to the desired state in the request.
SET KNOB	Name/value pair to control some MBM/PBM capabilities	Coded into the Image is a list of variable names that can be modified.
GET KNOB	The value currently maintained for the named variable is returned.	Check to see if the name is in the list and return it's current value in the response.
READ	Allow debug read of physical memory or I/O.	Check on validity of request and if valid, read physical memory space or direct I/O space. For debug.
WRITE	Allow debug write of physical memory or I/O.	Check on validity of request and check MMU protection privileges to write in the space so as not to cause protection violations. If not protected, write the block. For debug.

*Miscellaneous Command Handling*

Fig. 78

Command	Arg Count	Arguments	Result	Handling
Show_config	0		See Section "Show Configuration with FRU Data"	Make requests to PMU Server
Reset	2	1-Partition No 2-Sub Partition No	Returns OK or error	Send Reset Partition to PMU Server
Power_on	2	1-Partition No 2-Sub Partition No	Returns OK or error	Send Power On Partition to PMU Server
Power_off	2	1-Partition No 2-Sub Partition No	Returns OK or error	Send Power Off Partition to PMU Server
Halt_on	2	1-Partition No 2-Sub Partition No	Returns OK or error	Send Halt on Partition to PMU Server
Halt_off	2	1-Partition No 2-Sub Partition No	Returns OK or error	Send Halt Off Partition to PMU Server
Prepare_EV7_List	2-16	1-MBM Rack-thumb-wheel, 2-Ev7 Id (0-7) up to 8 pairs	OK if all elements are in the same hard partition or free pool	Saves this value in MBM RAM for use with the next Add EV7s, Free EV7s. Lasts until next Prepare EV7 List.
Add_Ev7s	2	1-Partition No 2-Sub Partition No	Take the values in the Ev7 list and add it to the partition.	Send command to PMU Server.
Free_Ev7s	0		Take the values in the Ev7 list and remove them from the partition indicated.	Send command to PMU Server.
Save_partition	2	1-Partition No 2-Sub Partition No	The partition database gets stored to NVRAM.	Send command to PMU Server.
Destroy_partition	2	1-Partition No 2-Sub Partition No	Reset & Free all Ev7s from partition.	Send command to PMU Server.
Ev7_test	3	1-MBM Rack-thumb-wheel, 2-Ev7 Id (0-7), 3-Test Number	Test Status	Send a Ev7 Start Test request to the CMM.
Add_cable	5-6	1-Source - MBM Rack-thumb-wheel, 2-Ev7 Id (0-7), 3-Port(N,S,E,W), 4-Destination - MBM/PBM Rack-thumb-wheel, 5- Ev7 Id(0-7) or IO7 Id(0-3), 6-Port(N,S,E,W) or blank when IO7	This command assists in locating the proper connector pair to connect the cable. The leds at each connector are lit until the connection is complete.	The commands Set Cable Test Signal State and Get Cable Test Signal State are sent to the appropriate MBM and PBM to cause the leds to light and check the connection itself.
New_cabling	0		Redo cabling tests.	Send Reconfigure Cabling to PMU Server.
Show_cabling	0		Displays a list of IP & IO Cabling	Send Retrieve Cabling Configuration to PMU Server.
Virt_console	3	1-Partition No, 2-Sub Partition No, 3-COM Port(1,2)	Open a session with primary EV7 & intercept COMx Port Data.	Use PutChar streams for both display and keyboard data until the keyboard data sequence 'ESC'ESC'S'M' is recognized as an exit of the session.
Get_fans	1	1-MBM/PBM Rack-thumb-wheel	RPM and threshold that fans are running at.	Determine appropriate IP address for destination and send a Get Fan RPM Speed message.
Set_fan	3	1- MBM/PBM Rack-thumb-wheel, 2-Instance of Fan, 3-RPM	Error or OK	Determine appropriate IP address for destination and send a Set Fan RPM Speed message.
Error_counts	0		Returns a list of the error counts on all MBM/PBM error logs.	Send Error Log Count request to each MBM/PBM.
Error_clear	1	1- MBM/PBM Rack-thumb-wheel	OK	Send Error Log Clear request to destination
Get_errors	1	1-count of the number of errors to be reported on each device.1	A list of the last Error Messages in English as it would appear on the OCP with any qualifying data formatted as appropriate. This is repeated for each MBM and PBM.	Get the ERROR LOG COUNT from each micro. Send Error Log Entry Retrieval Requests to each micro using the highest number as the 1 <sup>st</sup> request.

Fig. 79A

Command	Arg. Count	Arguments	Result	Handling
Get_time	0		Date and time is displayed as dd/mm/yy hh:mm:ss	Use Get base Time command
Set_time	1	1-Date and Time entry in format: "dd/mm/yy-hh:mm:ss"	Redisplays date and time	Set Base Time and Announce Base Time Change is sent to all MBMs.
Req_knobs	2-3	1- MBM/PBM Rack-thumb-wheel, 2- Device("MBM", "PBM", "CMM"), 3- If CMM in 2, then number (0-3)	Names and values of all possible knobs are listed.	Request Knob command for all possible knobs for that device.
Set_knob	4-5	1- MBM/PBM Rack-thumb-wheel, 2- Device("MBM", "PBM", "CMM"), 3-If CMM in 2, then number (0-3) 2-Knob name, 3-Knob Value	OK	Set Knob on requested micro.
Firmware_version	3-4	1- MBM/PBM Rack-thumb-wheel, 2- Device("MBM", "PBM", "CMM"), 3-If CMM in 2, then number (0-3) 4-Module ("CMM", "FPGA", "SRAM", "XSROM", "MBM", "PBM", "CMM_FSL", "MBM_FSL", "PBM_FSL", "PBM_FPGA")	Returns the version number	Report Firmware Version Command
Firmware_upgrade	4-5	1- MBM/PBM Rack-thumb-wheel, 2- Device("MBM", "PBM", "CMM"), 3-If CMM in 2, then number (0-3) 4-Module ("CMM", "FPGA", "SRAM", "XSROM", "MBM", "PBM", "CMM_FSL", "MBM_FSL", "PBM_FSL", "PBM_FPGA") 5-TFTP Server IP Address	Makes the terminal into a PPP serial link making TFTP requests until completion of the transfer or a timeout occurs. Possible return values are: "Complete", "Timeout", "File too long", "File too short"	Send the Upgrade Firmware request to the MBM or PBM or CMM. Make the backup copy where required. MBM has a copy of CMM program.

Fig. 79B

Command	Arg Count	Arguments	Result	Handling
Load_test_version	4-5	1- MBM/PBM Rack-thumb-wheel, 2- Device("MBM", "PBM", "CMM"), 3-If CMM in 2, then number (0-3) 4-Module ("CMM", "FPGA", "SRAM", "XSROM", "MBM", "PBM", "CMM_FSL", "MBM_FSL", "PBM_FPGA") 5-TFTP Server IP Address	Makes the terminal into a PPP serial link making TFTP requests until completion of the transfer or a timeout occurs. Possible return values are: "Complete", "Timeout", "File too long", "File too short"	Send the Load Test Version Command to the MBM or PBM or CMM, which maintains a copy of the program in MBM memory.
Disable_test_version	3-4	1- MBM/PBM Rack-thumb-wheel, 2- Device("MBM", "PBM", "CMM"), 3-If CMM in 2, then number (0-3) 4-Module ("CMM", "FPGA", "SRAM", "XSROM", "MBM", "PBM", "CMM_FSL", "MBM_FSL", "PBM_FPGA")	OK	Send Disable_test_version command

CLI Commands

Fig. 79 C





[illegible]

Capability	Ramification during MBM failure
Proxy Forwarding	LAN messages to the CMM fail.
CMM presence watchdog	There is no notification of failure
TFTP Server	CMM is unable to be firmware upgraded
Error repository & distribution	CMM is unable to log errors
Power hierarchy	Partition power changes cannot occur
Time Services	CMM does not receive regular time updates
Virtual Console Terminal	Console input/output unavailable if primary in path
SRM Env. Var. Repository	Env. Writes fail; SRM write callbacks fail.

MODEM KNOBS FOR CONNECTION  
TO CLIPORT

Command	OS/ SRM Up	All EV7s	Maj. Grp.	Comment
Distribute Partition Database with EV7 change, Add EV7, Delete EV7	T	T	T	Provided the new EV7 is still in the majority group and routable.
Set Partition Delta Time, Store Environment Variables, Assign Sub partitions, Assign Memory & IO7	X	X	T	This affects the database; but when joined back again majority wins.
Reset, Halt, Quiesce, Continue	T	T	X	This doesn't affect the non-volatile database.
Power On, Power Off, Change Primary	X	X	X	Never allowed on a split partition

### Operation Limitations in a degraded system

Fig. 82

Operations	Structures	Distribution Commands	RAM	NVR
The LAN Group protocol messages use either broadcast or request/response messages in forming a group.	GroupId(RAM), MajGID(RAM), Micro-processorSet(NVRAM)	NewGroup, Accept, Join, SetMembership	x	x
The Group Leader, after forming a new group, checks the copy of all members' partition databases and distributes the copy. EV7 changes noted by the PMU Server are distributed via a partition database change. The partition coordinator, when reconfiguring the partition, may need to distribute commands that change the volatile copy of the partition database.	EV7/IO7, memory locations, assignments and status.	Request partition database, Distribute partition database	x	x
The PMU Server initialization includes the cable testing and distribution of that volatile database information	Cable Configuration	Retrieve Cabling Configuration	X(not distributed)	
The DHCP Server distributes the list of DHCP leases and their changes.	DHCP Leases	Distribute DHCP Lease Data	x	x
The Partition Coordinator distributes to all members any changes in the status of the partition's state and attributes to allow fail-over recovery to another partition coordinator. Changes to Memory, IO7 and Community assignments among the sub-partitions. Partition states are affected by the ongoing starting, routing, loading, halting, resetting and power controls on the entire partition. Attribute fields on a partition are: 1) OS Watchdog Interval and Action Mask, 2) BB_Watch Delta Time, 3) SRM Environment Variables.	Partition State and attribute fields(RAM). The state and OS Watchdog is kept in volatile RAM and all other attributes are stored in NVRAM location for that partition.	Set Partition State and attributes or Distribute One Partition's Database	x	x
MBM maintains in RAM status on it's own CMMs, EV7s and memory. I2C data, error log count, Knobs and OCP data is maintained in RAM.	CMM EV7 Status, I2C sensor and EEROM values, volatile Knobs.	MBM Report Configuration	X(not distributed)	
MBM maintains the current use of the OCP switch settings and some Knobs. Default is entire system enclosure.	OCP switch control, permanent Knobs.	OCP to Partition Assignment	X(not distributed)	X(not distributed)
PBM maintains a RAM copy of it's own IO7 Ids, I2C data and error log count.	IO7 riser Ids, I2C sensor and EEROM values.	PBM Report Configuration, Receive Cable ID	X(not distributed)	
PBM receives from SRM the PCI Configuration Data and retrieves it on request. MBM, PBM and CMM knob data are kept in NVRAM to tailor behavior.	PCI Config Space(RAM), Knob Data.	Store PCI Slot Info, Read PCI Slot Info, Set Knob Data, Get Knob Data	X(not distributed)	X(not distributed)

*Data Base Grouping*

**Fig. 83**

84,002\ IN FLASH



REPLICATED DATABASE

001600-34125960

84,000

IN RAM

VOLATILE PARTITION DB									
N/S	EW	HARD	SUB	PRIMARY	CABLE CONNECTION				
0	0	7	1	N	N	S	E	W	PID
.	.	.	.	Y	x,y	x,y	x,y	x,y	2i
.	.	.	.	N	.	.	.	.	.
.	.	.	.	...	.	.	.	.	.
x	y	z	s	p	.	.	.	.	i

x: 0-15 y: 0-15 z: 0-255 s: 0-255 t: 0-255 i: 0-255  
 CABLE CONNECTION: -i MEANS DISCONNECTED  
 VARIABLE SIZE; DENSE;

84,030

ROUTING INFO	
NUMBER OF ENTRIES	(x,y)
LOGICAL PID	
#1 RBOX_ROUTE	
#2 RBOX_ROUTE	
...	
LOGICAL PID	(x,y)
#1 RBOX_ROUTE	
#2 RBOX_ROUTE	
...	
PER HARD PARTITION	
VOLATILE	
VARIABLE LENGTH	
MAX SIZE : 256 ENTRIES	

BASE TIME	84,020
NON-VOLATILE	
FIXED:	84,050

EV7 STATUS	
CPU STATUS	
0	GOOD
.	NOT PRESENT
.	BAD
x	...
x: 0-7	
PER MBM	
LOCAL TO MBM	(L)


(L) LOCAL TO MBM  
 (T) TEMPORARY/SHORT LIVED

REPLICATED DATABASE

FIG. 84B

Fig. 85

00T600-0342520




PBM Hardware Overview

Fig. 86


Error Code	Device Type	Reporter	OGP/Client Text	Log	Alert	System	EEROM	Ecc Data	OGP
1	none	Anyone	Free Text	x	?	?		x	?
2	none	Anyone	Binary with no text	x	?	?		x	?
1	EV7	CMM	EV7 xx Failure Code xx on running OS	x	x	x		x	x
2	EV7	CMM	EV7 xx Failure in Routing to EV7 xx	x	X				
3	EV7	CMM	EV7 xx Power On Failed	x	x				x
4	EV7	CMM	EV7 xx Failed on Test xx with Status xx	x	x				
5	EV7	CMM	EV7 xx Overheated at xxx Fahr.	x	x	x			x
6	EV7	CMM	EV7 xx xx.x Power at xx.x	x	x	x			x
7	RIMM	CMM	Memory Test xx Failure for RIMM xx	x	x			x	x
8	FPGA	CMM	CMM x FPGA Failure xx	x	x				x
9	CMM	CMM	CMM x POST Error xx	x	x			x	x
10	CMM	CMM	CMM x Failsafe Load Required	x	x		X		x
11	CMM	CMM	CMM x Failed to Start Test xx	x	x		X	x	x
12	I2C	CMM, MBM	I2C Failure on MBM xx CMM x	x	x	x			x
13	MBM	MBM	MBM Post Failure xx	x	x			x	x
14	Power Supply	MBM	Power Supply x can't power on	x	x	x			x
15	LAN	MBM	No Peer Communication on LAN	x		x			x
16	UART	MBM	COM Port x Failure	x	x				x
17	MBM/PBM	MBM/PB M	Fail Safe Load Required	x	x				x
18	LAN	MBM/PB M	In Isolated Group on LAN	x	x	x			x
19	Memory	MBM/PB M	Single/Multi bit Ecc Error	x	x			x	x
20	WDT	MBM/PB M	MBM Watchdog Reset	x	x	x			x
21	WDT	MBM	Watchdog Expired on Partition xx	x	x	x			x
22	IO7	PBM	IO7 xx Drawer not accessible	x	x	x			x
23	Temp	MBM/PB M	Temperature too high xxx Fahr	x	x	x	X		x
24	EEROM	CMM, MBM/PB M	EEROM xx not accessible	x	x				x
25	OCF	MBM	OCF not accessible	x	x				
26	IO7	MBM	EV7 xx not connected to IO7 xx	x		x			x
27	EV7	MBM	Virtual Console at EV7 xx busy	x					x





Shared Ram Communiaction

Fig. 88



MBM to CMM communication

Fig. 89






Fig. 90





## CMM com port connection

Fig. 92



The Telnet Session

Fig. 93

# REQUEST FORMAT

Size (dec)	Start (hex)	End (hex)	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4	0	3	Originator IP address							
4	4	7	Destination IP address							
4	8	B	Identifier							
2	C	D	Command Code							
n	E	n+E	Data (optional)							

Request Format

Fig. 94

001E50" 05h25960

**RESPONSE FORMAT**

Size (dec)	Start (hex)	End (hex)	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4	0	3	Originator IP address							
4	4	7	Destination IP address							
4	8	B	Identifier							
2	C	D	Response Code							
2	E	F	Status (See App. A)							
n	10	n+10	Data (optional)							

Response Format

Fig. 95

001660-35125920



Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Originator IP address (0)							
Destination IP address (FFFFFFFFh)							
Identifier (GroupID)							
Command Code							
SM LAN message							

Train Message Header Format

Fig. 96

Command Descriptor	Code
New group	0101h
Accept group offer	0102h
Reject group offer	0103h
Join group	0104h
Probe microprocessor	0105h
I-am-alive	0106h
Report Conflicting Address	0107h
Set Membership Configuration	0108h

*LAN Formation Group*

Fig. 97



Command Descriptor	Code
Get CMM State	0310h
Get MBM Configuration	0321h
Get PBM Configuration	0322h
Get Partition Database	0323h
Distribute Partition Database	0324h
Get System Topology	0330h
Store PCI Slot Info	0331h
Get PCI Slot Info	0332h
Get Own Partition Number	0333h

System Discovery Group

Fig. 99

Command Descriptor	Code
Create Partition	0401h
Set Partition Attributes	0402h
Move EV7s to Partition	0403h
Remove EV7s from Partition	0404h
Save Partition Assignment	0405h
Start Partition	0406h
Reset Partition	0407h
Power On Partition	0408h
Power Off Partition	0409h
Halt Partition	040Ah
Add EV7s to Running Partition	040Bh
Delete EV7s from Running Partition	040Ch
Switch Primary EV7	040Dh
Destroy Partition	040Eh
Continue Partition	040Fh
Compute Routing	0410h
Configure RBOX/CBOX	0411h
Set Partition State	0412h
Get State of OCP switches	0413h
OCP Switch Assignment	0414h
Power On/Off	0415h
System Event	0416h
Assign Sub Partitions to Community	0417h <sup>1</sup>
Get Hard Partition Memory Assignments	0418h
Assign Memory Block to Sub Partition	0419h
Assign IO7 to Sub Partition	041Ah
Store Environment Variables	041Bh
Get Environment Variables	041Ch

### Partition Control Group

Fig. 100

<sup>1</sup> Communities are to be implemented at a later phase of development.

Command Descriptor	Code
EV7 Reset On/Off	0501h
EV7 Pulsed Reset	0502h
EV7 Halt On/Of	0503h
EV7 Quiesce	0504h
EV7 RBOX/CBOX Config	0505h
Request EV7 Start Test	0506h
Load Image	0507h
Load & Run SRM	0508h

EV7 Setup Group

Fig. 101

Command Descriptor	Code
Set Cable Test Signal State	0601h
Get Cable Test Signal State	0602h
Send Cable ID	0603h
Receive Cable ID	0604h
Get MBM IP Cabling	0605h
Get PBM IO Cabling	0606h
Get Cabling Configuration	0607h
Reconfigure Cabling	0608h

Cable Test Group

Fig. 102





Command Descriptor	Code
Get Firmware Version	0801h
Upgrade Firmware	0802h
Load Test Version	0803h
Disable Test Version	0804h

#### Firmware Load and Upgrade Group

Fig. 104

Command Descriptor	Code
Get Voltage Readings	0901h
Get Temperature Readings	0902h
Get Fan RPM Readings	0903h
Set Fan RPM Speed	0904h
Set OCP Display Data	0905h
Set Attention Indicator	0906h
Get Switch State	0907h
Get Power Supply State	0908h

Environmental Retrieval Group

Fig. 105

001600-05125510



Command Descriptor	Code
Error Reporting	0B01h
Get Error Log Count	0B02h
Error Log Clear	0B03h
Get Error Log Entry	0B04h

#### Error Logging Group

Fig. 107

00FEE6D-05H25960



Command Descriptor	Code
Get Base Time	0D01h
Set Base Time	0D02h
Distribute Base Time change	0D03h
Set Partition Delta Time	0D04h
Get Partition Delta Time	0D05h

Date/Time Group

Fig. 109

00000000000000000000000000000000

Command Descriptor	Code
Get Knob	0E01h
Set Knob	0E02h
Unrecognized Response	0E03h
Distribute DHCP Lease Data	0E04h
Read	0E05h
Write	0E06h

Miscellaneous Group

Fig. 110

001663-6425560